


Installation Instructions of float switch Part Number 106-TEG-10 for LB and HS series.

- Connection to be done by a qualified electrician only -

1

Necessary Parts for Installation.



Scope of delivery 106-TEG-10.

2

Unscrew the Cable Connection.




3

Unplug the connectors.



4

Introduce the cable Connectors through the Float Adapter.



5

Match the Connectors using the following table.



	With	
	With	
	With	
	With	

Sealing should be oriented to the pump.

Correct Float Switch setting for **HS series**.

6

Cable Facing Out.



7

Screw the Cable length Adjuster Clip to the Handle.



Correct Float Switch setting for **LB series**.

8

Cable Facing In.



9

Screw the Cable length Adjuster clip to the Handle



(The Screw from original cable entry fixation, should be reused to fix the cable clip)