

INSTRUKCJA OBSŁUGI

HUŚTAWKA OGRODOWA MINGO SWINGO RELAX

MIN-27959 MIN-27966







MODEL


MIN-27959 BEŻOWY

MIN-27966 SZARY


1. CZĘŚCI ORAZ MONTAŻ

A	 / x2	N	 / x1
B	 / x2	O	 M6*25 / x4
C	 / x1	P	 M6*30 / x2
D	 / x1	Q	 M6*45 / x6
E	 / x2	R	 M6*60 / x4
F	 / x4	S	 M6*55 / x4
G	 / x1	T	 M8*85 / x4
H	 / x1	U	 / x2
I	 / x2	V	 / x2
J	 / x1	W	 / x4
K	 / x2	X	 Duża / x4
L	 / x2	Y	 Mała / x4
M	 / x1		


KROK 1




KROK 2




KROK 3



KROK 4



KROK 5



KROK 6

